

Important notice: MR-8mkII with AD12-1000 AC Adapter (Newer Models)

Thank you for the purchase of your **Fostex** product. If your **MR-8mkII** came with **A/C adapter model AD12-1000** please confirm that the latest version software V1.05 is installed on the unit. If the unit powers on with V1.04 or any other software version other than V1.05, PLEASE update your software for using the AD12-1000 adapter.



This will avoid an intermittent failure of the phantom power feature. **(MENU>INPUT>Phantom Power>On)**. If you are not familiar with this feature, please refer to page 137 of your manual for details.

Updating your software is very simple and easy to do. Please go to **www.fostexusa.com** and go to the **software update** section of the site (http://fostexusa.com/index.php?file=support/software_updates). There you will find **software version V1.05**. Please download the software and install it in your MR8mkII. When you download the software you will also receive a PDF file with instructions how to perform the update.

Caution when powering on MR-8mkII (All models)

If you use the phantom power feature it is recommended that you do not leave your microphone connected when powering up. Please disconnect your phantom

powered microphone before turning off the unit and do not re-connect it until the unit is fully powered up. Please note that phantom power is only available via the XLR input connection, 1/4 inch inputs do not supply phantom power.

If you have questions or concerns please contact **support@fostexusa.com**. Please check the Fostex website periodically for updates and other product support information. For tips and recording advice please check our **User Forums** and **Knowledgebase**.